
















# Working with channels:











## To add a channel:

- From the main menu, select  (**User Data**), then  (**Channels**).
- Do *one* of the following:
  - If there are no channels programmed in the transceiver, press  (**Add**).
  - If there are some existing channels programmed in the transceiver, scroll to the channel after which you want to add the new channel, press (**Options**),
- Scroll to **Add**, then press  (**Select**) to add a channel.
- Enter the name that you want to use for the channel.
- Press  to move to the **Tx** entry, and enter the transmit frequency
- Press  to move to the **Rx** entry. and enter the receive frequency
- Press  to move to the **Mode** entry.
- Press  or  to scroll to the mode that you want to use, then press **OK**.
- Press  (**Save**).
- Press  to move to the **Power** entry.
- Press  or  to select the value that you want to use.
- Press  (**Save**) to save the information.
- Press  (**Close**).








## Editing a channel:

- From the main menu, select  (**User Data**), then  (**Channels**).
- Press  or  to scroll to the channel that you want to edit, then press **OK**.

## Moving a channel:

- From the main menu, select  (**User Data**), then  (**Channels**).
- Press  or  to scroll to the channel that you want to move, press  (**Options**),
- Scroll to **Move**, then press  (**Select**).
- Press  or  to scroll to the new location for the channel, then press  (**Place**).
- Press  (**Close**).

## Deleting a channel:

- From the main menu, select  (**User Data**), then  (**Channels**).
- Press  or  to scroll to the channel that you want to delete, press  (**Options**),
- Scroll to **Delete**, then press  (**Select**) to delete the channel.
- Press  (**Close**).